

## Lan and Internet Remote Connectivity<sup>1</sup>



### **6. IP/Serial Port Converter for local LAN access (IP/Serial #1) includes**

- IP/Serial Port Converter
- Pre-configuration of network IP address provided at time of order
- Phone support during initial installation

This option allows the user to remotely control the VM-3 Character Generator (VM3) through a LAN. The VMConsole program is required.



### **7. IP/Serial Port Converter for Internet Access (IP/Serial #2) includes**

- IP/Serial Port Converter
- Pre-configuration of static IP address provided at time of order
- Phone support during initial installation

This option allows the user to remotely control the VM-3 Character Generator (VM3) through the Internet. The VMConsole program is required. Also requires dedicated cable/DSL modem with static IP.

---

<sup>1</sup> These items require the purchase of the VMConsole for Windows® (Con#1)